



# INCUBATOR UNDER QUILT

## SIZING GUIDE



### HOW TO MEASURE

**HEIGHT**  
From the top of your head to the bottom of your feet.

**WIDTH**  
Measure across the widest point of your backside. Covers up to **44 in (118 cm)** — use a top quilt for side gaps.

### FIT & SLEEPING

If you tend to sleep cold, consider ordering **10° lower** than you intend to primarily use the quilt.

In-between sizes are recommended to **size down**.

### DESIGN NOTES

The Incubator covers you from head to toe. Its standard 44 in (118 cm) width suits most body types when paired with a top quilt.

A contoured, differential cut follows your body to eliminate cold spots and trap warmth.

## SIZE CHART

Measurement	Short	Standard	Long
Fits height	5'2"–5'7" 157–170 cm	5'7"–6'2" 170–188 cm	6'2"–6'7" 188–201 cm
Quilt length	73 in 185 cm	78 in 198 cm	83 in 211 cm
Quilt width	44 in 118 cm		
Style	Under quilt		
Type	Full-length		

## SPECIFICATIONS

Fill power	850-fill (standard) or 950-fill down (depending on availability)
Materials	Down-proof shell fabric with DWR coating; adjustable suspension lines
Pack size	<ul style="list-style-type: none"><li>40°F rating: ~4.5 L</li><li>30°F rating: ~5.5 L</li><li>20°F rating: ~8.5 L</li></ul>

Intended use: underquilt for hammock use — All measurements approximate.